

PARTS CATALOG

Series SLZ


Ceiling Cassettes

R32/R410A

Indoor unit
[Model Name]

[Service Reference]

SLZ-M15FA3	SLZ-M15FA3.TH
SLZ-M15FA3-ET	SLZ-M15FA3-ET.TH
SLZ-M25FA3	SLZ-M25FA3.TH
SLZ-M25FA3-ET	SLZ-M25FA3-ET.TH
SLZ-M35FA3	SLZ-M35FA3.TH
SLZ-M35FA3-ET	SLZ-M35FA3-ET.TH
SLZ-M50FA3	SLZ-M50FA3.TH
SLZ-M50FA3-ET	SLZ-M50FA3-ET.TH
SLZ-M60FA3	SLZ-M60FA3.TH
SLZ-M60FA3-ET	SLZ-M60FA3-ET.TH



INDOOR UNIT

CONTENTS

1. SERVICE PARTS LIST 2

SERVICE MANUAL (OCH932)

Mr. SLIM

GRILLE PARTS

SLP-2FA (Standard)

SLP-2FAL (with Signal Receiver)

SLP-2FALM3 (with Receiver and Remote Controller)


SLP-2FALMN3 (with Receiver and Remote Controller)

SLP-2FAE (with i-See sensor)

SLP-2FALE (with Receiver and i-See sensor)

SLP-2FALME3 (with Receiver, i-See sensor, and Remote Controller)

SLP-2FALMEN3 (with Receiver and Remote Controller)




1. The part quantity below indicates the required number of pieces per unit.

2. The circled No. indicates that the part is not shown in the figure.

No.	Parts No.	Parts Name	SLP-2FA	SLP-2FAL	SLP-2FALM3	SLP-2FALMN3	SLP-2FAE	SLP-2FALE	SLP-2FALME3	SLP-2FALMEN3	Wiring diagram symbol	Remarks [Drawing No.]
1	E27 C26 003	AIR OUTLET GRILLE	1	1	1	1	1	1	1	1		Except VANE-related parts
2	E27 C26 010	INTAKE GRILLE	1	1	1	1	1	1	1	1		Except AIR FILTER
3	E27 C26 100	AIR FILTER	1	1	1	1	1	1	1	1		
4	E27 C29 975	CORNER PANEL (i-See sensor)					1	1	1	1		
5	E27 0M2 975	CORNER PANEL (Signal Receiver)		1	1	1		1	1	1		
6	E27 3K9 317	WIRELESS REMOTE CONTROLLER BOARD		1	1	1		1	1	1	W.B	
7	E27 C26 975	CORNER PANEL	4	3	3	3	3	2	2	2		Includes safety strap
8	E27 C26 037	AUTO VANE -1	2	2	2	2	2	2	2	2		GREEN
9	E27 C27 037	AUTO VANE -2	2	2	2	2	2	2	2	2		BLUE
10	E27 C26 303	VANE MOTOR-1	2	2	2	2	2	2	2	2	MV	GREEN
11	E27 C27 303	VANE MOTOR-2	2	2	2	2	2	2	2	2	MV	BLUE
12	E27 C26 946	COUPLING-1	2	2	2	2	2	2	2	2		GREEN
13	E27 C27 946	COUPLING-2	2	2	2	2	2	2	2	2		BLUE
14	E27 C26 044	VANE BUSH	8	8	8	8	8	8	8	8		
15	E27 6P2 426	WIRELESS REMOTE CONTROLLER			1	1			1	1		
16	E27 D44 083	REMOTE CONTROLLER HOLDER			1	1			1	1		
⑰	E27 C26 033	WIRE HOOK	2	2	2	2	2	2	2	2		
⑱	E27 C28 087	JUNCTION CABLE (Signal Receiver)		1	1	1		1	1	1		
⑲	E27 C27 087	JUNCTION CABLE (i-See sensor)					1	1	1	1		

ELECTRICAL PARTS

SLZ-M15FA3 SLZ-M25FA3 SLZ-M35FA3 SLZ-M50FA3 SLZ-M60FA3
SLZ-M15FA3-ET SLZ-M25FA3-ET SLZ-M35FA3-ET SLZ-M50FA3-ET SLZ-M60FA3-ET




1. The part quantity below indicates the required number of pieces per unit.

No.	Parts No.	Parts Name	SLZ-M15FA3.TH	SLZ-M15FA3-ET.TH	SLZ-M25FA3.TH	SLZ-M25FA3-ET.TH	SLZ-M35FA3.TH	SLZ-M35FA3-ET.TH	SLZ-M50FA3.TH	SLZ-M50FA3-ET.TH	SLZ-M60FA3.TH	SLZ-M60FA3-ET.TH	Wiring diagram symbol	Remarks [Drawing No.]
1	E27 162 375	TERMINAL BLOCK	1	1	1	1	1	1	1	1	1	1	TB4	(S1,S2,S3)
2	E27 156 375	TERMINAL BLOCK	1	1	1	1	1	1	1	1	1	1	TB5	(1,2)
3	E27 5P0 447	INDOOR CONTROLLER BOARD	1	1	1	1	1	1	1	1	1	1	I.B	
4	E27 648 382	FUSE	1	1	1	1	1	1	1	1	1	1	F1	T6.3AL250V
5	E27 45U 777	ELECTRICAL CONTROL BOX	1	1	1	1	1	1	1	1	1	1		
6	E27 81T 289	BOARD CASE	1	1	1	1	1	1	1	1	1	1		

FUNCTIONAL PARTS

SLZ-M15FA3.TH
 SLZ-M25FA3.TH
 SLZ-M35FA3.TH
 SLZ-M50FA3.TH
 SLZ-M60FA3.TH
 SLZ-M15FA3-ET.TH
 SLZ-M25FA3-ET.TH
 SLZ-M35FA3-ET.TH
 SLZ-M50FA3-ET.TH
 SLZ-M60FA3-ET.TH



FUNCTIONAL PARTS

1. The part quantity below indicates the required number of pieces per unit.

No.	Parts No.	Parts Name	SLZ-M15FA3.TH	SLZ-M15FA3-ET.TH	SLZ-M25FA3.TH	SLZ-M25FA3-ET.TH	SLZ-M35FA3.TH	SLZ-M35FA3-ET.TH	SLZ-M50FA3.TH	SLZ-M50FA3-ET.TH	SLZ-M60FA3.TH	SLZ-M60FA3-ET.TH	Wiring diagram symbol	Remarks [Drawing No.]
1	E27 C12 290	BASE	1	1	1	1	1	1	1	1	1	1		
2	E27 C13 124	DRUM-B	1	1	1	1	1	1	1	1	1	1		
3	E27 C12 808	LEG-1	2	2	2	2	2	2	2	2	2	2		
4	E27 C12 124	DRUM-A	1	1	1	1	1	1	1	1	1	1		
5	E27 C12 809	LEG-2	2	2	2	2	2	2	2	2	2	2		
6	E27 C12 092	INNER COVER ASSY	1	1	1	1	1	1	1	1	1	1		
7	E27 K49 620	INDOOR HEAT EXCHANGER	1	1	1	1								
7	E27 33A 620	INDOOR HEAT EXCHANGER					1	1						
7	E27 K52 620	INDOOR HEAT EXCHANGER							1	1				
7	E27 K53 620	INDOOR HEAT EXCHANGER									1	1		
8	E27 C12 300	INDOOR FAN MOTOR	1	1	1	1	1	1	1	1	1	1	MF	
9	E27 C12 105	MOTOR MOUNT	3	3	3	3	3	3	3	3	3	3		3 pcs/set
10	E27 C12 502	TURBO FAN	1	1	1	1	1	1	1	1	1	1		
11	E27 K05 097	FAN WASHER & NUT	1	1	1	1	1	1	1	1	1	1		
12	E27 C12 091	CONNECTOR COVER	1	1	1	1	1	1	1	1	1	1		
13	E27 C12 090	CONNECTOR BOX	1	1	1	1	1	1	1	1	1	1		
14	E27 C12 509	BELL MOUTH	1	1	1	1	1	1	1	1	1	1		
15	E27 436 524	DRAIN PLUG	1	1	1	1	1	1	1	1	1	1		
16	E27 C12 700	DRAIN PAN	1	1	1	1	1	1	1	1	1	1		
17	E27 C12 648	COIL SUPPORT	1	1	1	1	1	1	1	1	1	1		
18	E27 C12 308	ROOM TEMP. THERMISTOR	1	1	1	1	1	1	1	1	1	1	TH1	
19	E27 C12 307	PIPE TEMP. THERMISTOR/ LIQUID/GAS	1	1	1	1	1	1	1	1	1	1	TH2,TH5	Combined type
20	E27 C12 145	FLOAT SWITCH	1	1	1	1	1	1	1	1	1	1	FS	
21	E27 81T 355	DRAIN PUMP	1	1	1	1	1	1	1	1	1	1	DP	
22	E27 C12 702	DRAIN HOSE	1	1	1	1	1	1	1	1	1	1		
23	E27 C12 088	CONTROL BOX COVER	1	1	1	1	1	1	1	1	1	1		
24	E27 C13 006	COVER (DRUM-U)	1	1	1	1	1	1	1	1	1	1		
25	E27 C12 006	COVER (DRUM)	1	1	1	1	1	1	1	1	1	1		
26	E27 M08 097	WASHER	4	4	4	4	4	4	4	4	4	4		4 + 4 pcs/set
27	E27 M09 910	PIPE COVER	1	1	1	1	1	1	1	1	1	1		
28	E27 580 704	DRAIN SOCKET	1	1	1	1	1	1	1	1	1	1		

Mr. SLIM

mitsubishi electric corporation

HEAD OFFICE: TOKYO BUILDING 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN